





For the Legacy MPMS systems, the serial number is on the inside rear door.



For the MPMS XL, the serial number is located on the bottom rear near the incoming power.





For the Squid VSM, the serial number is located on the rear of the tower.



# System Serial Number Locations for PPMS, DynaCool and VersaLab systems

## 1) PPMS, PPMS EverCool, and PPMS EverCool-II:

(Example S/N PPMS-603)



(wooden cabinet models only)  
Front of PPMS Cabinet.  
Open door at bottom.  
Lower left side.



(all cabinet models)  
Back of PPMS Cabinet.  
Lower right corner.

## 2) DynaCool:



**Back of DynaCool cabinet.**

**Upper left, at the top of the electronics rack.**

## 3) VersaLab:



**Back of VersaLab unit.**

**Lower right, near vent gas port.**